

INTERCHANGABLE MOUNT INSTRUCTIONS



REMOVE THE MEDALLION FROM THE SHIELD BY UNSCREWING THE NUT FROM THE BACK OF THE SHIELD. THE MEDALLION WILL THEN SLIDE OUT FROM THE FRONT.



TAKE A 1/4" DRILL BIT AND DRILL OUT THE EXISTING HOLE TO MAKE IT LARGER.



PLACE THE T-NUT GIVEN INTO THE HOLE ON THE BACK OF THE SHIELD. PRESS THE NUT FIRMLY INTO THE LEATHER. (THE NUT DOES NOT HAVE TO BE FLUSH AGAINST THE LEATHER. WHEN YOU SCREW IN THE FRONT IT WILL SUCK INTO THE LEATHER.)



PLACE THE BASE PLATE ON TO THE FRONT OF THE SHIELD AND SCREW THE BOLT THROUGH THE MIDDLE. MAKE SURE THE SPRING BALL IS LINED UP AT THE BOTTOM. MAKE SURE THE BOLT IS TIGHT AND THE T-NUT SUCKS UP TO THE LEATHER IN THE BACK.



SLIDE THE SLIDE MOUNT PIECE ON THE BASE PLATE. GO FROM THE TOP DOWN. YOU WILL HEAR A CLICK WHEN THE MOUNT IS SECURE. (IF YOU HAVE THE MEDALLION, IT SLIDES ON THE SAME WAY). MOUNT SLIDES STRAIGHT UP TO REMOVE.



ALIGN THE GROVES TOGETHER WITH THE GOPRO CASE AND THE ALLUMINUM MOUNT. THE GOPRO CASE WILL SIT IN THE MIDDLE. MAKE SURE THE ALLUMINUM GROOVES ARE ON BOTH ENDS. SCREW THE BOLT IN TELL SNUG, NOT TO TIGHT. (CAN USE BLACK THUMB SCREW THAT COMES WITH GOPRO)



THE CAMERA AND MEDALLION SLIDE ON AND OFF DEPENDING ON WHAT YOU CHOOSE. PLEASE CHECK OUT THE OTHER MOUNTS AND ACCESSORIES ON THE WEBSITE KWMACHINEWORKS.COM